SEGA SATURN™

NetLink

Mouse Instruction Manual



The Net Link mouse gives you easy and convenient point-and-click control for your Sega Saturn™ Net Link web browser.

1. Make sure the power switch on your Sega Saturn is turned off.

2. Plug the Net Link mouse controller cable into either Sega Saturn controller port. Place the mouse on a mouse pad (included), or other flat surface, and position at a comfortable distance from your Sega Saturn.

3. Roll the mouse across the mouse pad, or other flat surface, to move the cursor on-screen.



Using Precision Control

- To move the cursor left or right, simply slide the mouse left or right on the mouse pad.
- To move the cursor up or down, simply slide the mouse up or down on the mouse pad.
- The buttons on the mouse duplicate the functions of Buttons A, B, C and Start on the standard Saturn controller.
- Push mouse Button A to perform the actions controlled by Button A on the standard Saturn controller. Push mouse Buttons B, C or Start to perform the functions associated with the respective buttons on the standard Saturn controller.
- Please see your Net Link browser manual for more detailed information on how to use your Net Link mouse to explore the Internet.

If you would like technical assistance with the Net Link mouse, please call Sega customer service at 1-800-SEE-SATURN.

The Net Link mouse is intended for use exclusively with the Sega Saturn and Net Link. Do not try to use the Net Link mouse with your computer or with any other entertainment system.

Sega is registered in the U.S. Patent & Trademark Office.
Sega Saturn and NetLink are trademarks of Sega.
© SEGA, P.O. Box 8097, Redwood City, CA 94063.
All rights reserved.